

Product picture




Parts list




Assembly instructions

轮杯带有轴承锁，可以消除轴承的晃动，减小虚位。
The Locking Rear Hub is equipped with a bearing lock,
which can eliminate the shaking of the bearing and reduce the play.



不要把螺丝锁的太紧，只需要轻轻锁住，保持轴承顺畅运转。
Don't lock the screw too tight, just lock it lightly to
keep the bearing running smoothly.



带锁后轮杯与后角大师搭配，可提供六种拉杆几何结构。
Locking rear hub are paired with the Rear Toe Master,
which is available in six links geometries.

