

Product picture









Parts list



Assembly instructions


-Page 1



Assembly instructions

-Page 2

车宽调整方案 Body wide solution



主销后倾角调整 Caster Angle adjusting

松开机米螺丝，前后滑动摆臂，可快速调整主销后倾角（卡斯蒂角）。
Loosen this set screw, slide the upper arm, The kingpin caster angle can be adjusted quickly.

