


Product picture



Parts list



Assembly instructions -Page 1

Notice: 98402 needs to be used with 98302.
Before assembly, please confirm that you already own 98302. 98302 needs to be purchased separately.



提醒：98402需要与98302配合使用。
安装前请先确认你已经拥有了98302。98302需要单独购买。




Tips:

小技巧:

You can remove a M1.6 Cup Head screw from the chassis to assist with installation.
你可以从车架上取出一颗M1.6杯头螺丝，用来辅助安装。




R1/R2/S




Ball cups are sold separately
球头胶单独出售

Assembly instructions -Page 2






Hard suspension setting 硬悬挂设定

Soft suspension setting 软悬挂设定



Assembly instructions -Page 3



Ball cups are sold separately
球头胶单独出售

