

Product picture



Parts list

CNC Alu.	CNC Alu.	Cup head
Main part	parts	M1.6*4
CNC	2 pcs	4 pcs
铝合金主体	CNC铝件	杯头螺丝
(Assembled 预组装)		



Steel spacers
M2*0.5
4 pcs
钢制垫片

Cup head
M1.6*4
2 pcs
杯头螺丝

Flat head
M2*5
2 pcs
平头螺丝






Assembly instructions -Page 1

仅支持无双金属舵机、AFRC、AGFRC (V1-V3) 金属舵机

Notice: only use for these brands of metal servos:

AFRC-ART, AFRC, AGFRC.(V1-V3)



Assembly instructions -Page 2

DA2 SERIES



= OK!

DA3 SERIES

= OK!

DA4 SERIES

= OK!



Steel spacers
M2*0.5
4 pcs
钢制垫片



Please add a spacer here when
you use it on DA3S or DA2.

当用无双3代和2代底盘时，
请使用一枚垫片在此处垫片。

