



No.98805

Roll Gear Box Lightning Version
旋转波箱 闪电版

※ 组装前，请透彻理解说明书的含义（可到微信群或Facebook小组提问）。

Before assembly, please understand the instruction thoroughly
(You could ask in WeChat group or Facebook group-“ DriftArt guide and share”) .

R.G.B. can unlock a very rich motor position, the center of gravity is ultra-low, ultra-high, motor at mid-position, high-position, and rear-position, etc. The H-shaped spacer can adjust the tightness of the belt in units of 0.1mm, giving greater freedom of setting.

旋转波箱可解锁极为丰富的马达位置，重心超低、超高、中置、高置、后置。H形垫片能够以0.1mm为单位调节皮带的松紧度，给设定更大自由。


Product picture





Parts list





Assembly instructions



Notice: Put the gearbox on the plane, check and adjust angles to the same.
注意：把波箱放在平面上观察并调整，使两片波箱角度一致。



 Spacers 垫片数		OK 	
Tighten 紧张度			
Resistance 运行阻力			
Engagement 皮带咬合度			

